


3-4. Using the storage features

List of storage features



1 Door pockets

2 Glove box

CAUTION


n Items that should not be left in the storage spaces

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- 1 Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- 1 Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.


Glove box

The glove box can be opened by pressing the lock release button and locked and unlocked using the premium master key or master key.




- 1 Open
- 2 Unlock
- 3 Lock

The following items are attached on the back of the glove box lid:



- 1 Tire pressure gauge (→P. 278)
- 2 Penlight (→P. 211)

n Bottle holder



The glove box can be used as a bottle holder. (Certain bottles may not be stored depending on their size or shape.)

n Penlight



- 1 Turn the bottom portion to remove it.
- 2 Insert batteries. (2 AA batteries, sold separately)
- 3 Install the bottom portion.
- 4 On/off

⚠ CAUTION

n Caution while driving

Keep the glove box closed.

In the event of sudden braking, an accident may occur due to an occupant being struck by the open glove box or the items stored inside.


⚠ NOTICE

n When using the bottle holder

Ensure that the cap on the bottle is tightly closed before storing the bottle in the bottle holder.

Failure to do so may cause liquid to leak onto the electrical components, resulting in a malfunction.

Door pockets



! CAUTION

n Caution while driving

When using the door pocket, do not insert items that are likely to roll about or that are taller than the top of the door pocket. In case of sudden braking, these items may fly out, resulting in an unexpected accident.